User Manual
Instrukcja Obsługi

FLASH



Mega FOAM Machine
+ Frame + Case

F5300003

1. INTRODUCTION

THANK YOU FOR PURCHASING MEGA FOAM MACHINE. FOR SAFETY REASONS AND TO ENSURE THE TROUBLE-FREE OPERATION, CAREFULLY READ THE INSTRUCTIONS.

2. SAFETY INFORMATION

- Please keep this User Manual for future consultation. If you sell the fixture to another user, be sure that they also receive this instruction booklet.
- Unpack and check carefully there is no transportation damage before using the fixture.
- Before operating, ensure that the voltage and frequency of power supply match the power requirements of the fixture.
- It's important to ground the yellow/green conductor to earth in order to avoid electric shock.
- Disconnect main power before servicing and maintenance.
- Use safety chain when fixes this fixture. Don't handle the fixture by taking its head only, but always by taking its base.
- Maximum ambient temperature is: 40ºC Don't operate it where the temperature is higher than this.
- In the event of serious operating problem, stop using the fixture immediately. Never try to repair the fixture by yourself. Repairs carried out by unskilled people can lead to damage or malfunction. Please contact the nearest authorized technical assistance center. Always use the same type spare parts.
- Do not connect the device to any dimmer pack.
- Do not touch any wire during operation and there might be a hazard of electric shock.
- To prevent or reduce the risk of electrical shock or fire, do not expose the fixture to rain or moisture.
- The housing must be replaced if they are visibly damaged.
- Do not look directly at the LED light spot while the fixture is on.

WARNING!





IMPORTANT!

Do not point strong light output from other fixtures at the **Mega FOAM Machine**, as intense illumination can damaged the equipment.




Figure 2. Lenses can focused sunlight and strong light, presenting a risk of fire and damage to the fixture. Shield or shade the head if necessary.

3. PRODUCT INFORMATION

- Power: 3000W
- Voltage: AC 110V/220V 50/60Hz
- Control Mode: Manual
- Coverage area: 110m^3
- Water frame capacity: 50l
- Net weight: 34,5 kg
- Weight (with case): 76,5 kg
- Dimensions: H(103)xW(111)xD(56) cm
- Dim. (case): H(120/wh.131)xW(120)xD(63) cm

4. INSTALLATION

The unit should be mounted via its screw holes on the bracket. Always ensure that the unit is firmly fixed to avoid vibration and slipping while operating. Always ensure that the structure to which you are attaching the unit is secure and is able to support a weight of 10 times of the unit's weight. Also always use a safety cable that can hold 12 times of the weight of the unit when installing the fixture. The equipment must be fixed by professionals. And it must be fixed at a place where is out of the touch of people and has no one pass by or under it.


5. MACHINE OPERATIONS STEPS

1. First check the switch of the Control Panel, which must be in the OFF state.



❶ CONTROL PANEL

2. Adjust the angle button and fix it.



❷ Machine fixing

The maximum angle of machine angle adjustment range is 45° and cannot be too high.

3. Open the Control Panel of the machine, and the check button must be in the OFF state.



❸ Up is CLOSE
Down is OPEN

4. Put the water pump directly into the foam water pail that has been deployed.

5. Plug in the power supply, turn on the fan and let it work for 30 seconds first.



❹ WATER PUMP

BE CAREFULL!!!

When shutting down, the water pump must be turned off first, and then fan will be turned off after 30 second first.

6. MACHINE DIAGRAM



Up - close
Down - open

Fan Switch

Pump Switch

Fuse: Protection against leakage and power failure.
(Please do not remove it at will)



6. OPERATION MODE OF FOAM POWDER



Art. No F5900348

Foam powder is divided into: red, green, yellow, purple, blue, white or other colors.

Scale: 1:200 scale and 1:300 scale

One kilogram of foam powder can be mixed with 200l water; one kilogram of foam powder can be diluted with 300l water.

The mixing powder is clear and transparent.

CAUTION: IT IS DIFFICULT TO CLEAN THE COLOR FOAM POWDER. PLEASE USE PROTECTIVE TOOLS.

7. MACHINE CLEANING AND MAINTENANCE



1. Start the fan first and then the water pump.

Shut down the water pump first and then the fan.

2. After using the machine, the machine water pump must be turned OFF first stop working.

3. Put the water pump into the prepared water. Press the machine angle to the minimum, witch the machine head down.

4. Turn on the water pump of the machine again, until spray is clear water.

5. Wipe clean, Put it in.



8. MATTERS NEEDING ATTENTION

1. When preparing for operation. The machine must switched ON and OFF, „Water Switch" is all closed.

2. When cleaning, the „water pump switch" must be turned OFF.

3. Please keep the machine out of the reach of children.

4. Due to the high power of the fan, please do not touch the inside of the machine when it is powered on. The power must be cut off.

5. The color of foam powder is not easy to clean. Please protect well.

6. The foam machine is working, foam, please do not spray on the childs head.

7. Foam into eyes or mouth. Please rinse with water in time. If you do not feel well, seek medical advice.

1. WPROWADZENIE

DZIĘKUJEMY ZA ZAKUP URZĄDZENIA MEGA FOAM MACHINE. ZE WZGLĘDÓW BEZPIECZEŃSTWA ORAZ W CELU ZAPEWNIENIA BEZAWARYJNEJ PRACY URZĄDZENIA NALEŻY DOKŁADNIE ZAPOZNAĆ SIĘ Z INSTRUKCJĄ.

2. ZASADY BEZPIECZENSTWA

- Instalacja powinna być przeprowadzana przez wykwalifikowany personel, aby zminimalizować ryzyko przypadkowego porażenia prądem.
- Przed instalacją urządzenia należy odłączyć urządzenie od sieci.
- Przed podłączeniem urządzenia do sieci energetycznej należy sprawdzić, czy nie jest ono uszkodzone mechanicznie. Jeżeli widoczne są jakiekolwiek ślady uszkodzenia należy niezwłocznie skontaktować się z dystrybutorem. Nie podłączać urządzenia do sieci elektrycznej.
- Nie należy korzystać z urządzenia w warunkach dużej wilgotności powietrza oraz w temperaturze powyżej 40°C
- Aby uniknąć uszkodzeń nie należy stosować rozpuszczalników organicznych do czyszczenia powłoki urządzenia.
- Urządzenie należy instalować na stabilnych konstrukcjach.
- Urządzenie powinno być zainstalowane w dobrze wentylowanym pomieszczeniu, w odległości co najmniej 15cm od najbliższej powierzchni (ściany, sufitu itp). Jednocześnie należy upewnić się, że otwory wentylacyjne nie są zatkane oraz wentylatory działają poprawnie.


UWAGA!





WAŻNE!

Nie kieruj silnego światła z innych urządzeń w **Mega Foam Machine**, ponieważ intensywne oświetlenie może uszkodzić sprzęt.



Rysunek 2. Soczewki mogą skupiać światło słoneczne i silne światło, stwarzając ryzyko pożaru i uszkodzenia urządzenia. W razie potrzeby należy osłonić lub zasłonić głowę.

3. INFORMACJE O PRODUKCIE

- Pobór mocy: 3000W
- Napięcie: AC 110V/220V 50/60Hz
- Sterowanie: Manualne
- Strefa pokrycia: 110m^3
- Pojemność pojemnika z wodą: 50l
- Waga netto: 34,5 kg
- Waga (z case): 76,5 kg
- Wymiary: W(103)xSz.(111)xGł.(56) cm
- Wym. (case): W(120/wh.131)xSz.(120)xGł.(63) cm

4. INSTALACJA

Po wyjęciu urządzenia z opakowania należy sprawdzić czy nie zostało ono uszkodzone podczas transportu. Przed podłączeniem do sieci elektrycznej należy upewnić się, że urządzenie zamocowane jest stabilnie. Producent nie ponosi odpowiedzialności za uszkodzenia spowodowane niestabilnym zamocowaniem urządzenia.

Podczas korzystania z urządzenia należy zadbać o poprawne podłączenie go do sieci elektrycznej oraz prawidłowe uziemienie. Należy upewnić się, że parametry sieci elektrycznej są zgodne z wymaganiami urządzenia. Wszelkie czynności obejmujące obsługę w zakresie podłączania urządzenia do sieci elektrycznej powinny być wykonywane przez wykwalifikowany personel.


5. MACHINE OPERATIONS STEPS

1. Najpierw sprawdź przełącznik Panelu Sterowania, który musi być w stanie WYŁĄCZONY (ZAMKNIĘTE).



❶ PANEL STEROWANIA

2. Wyreguluj kąt pochyłu urządzenia.



❷

Maksymalny kąt zakresu regulacji kąta maszyny wynosi 45° i nie może być zbyt duży.

3. Otwórz Panel sterowania urządzenia. Przycisk musi być w stanie WYŁĄCZONY.



❸ Góra to ZAMKNIĘTE
Dół to OTWARTE

4. Włóż pompę wody bezpośrednio do pojemnika na wodę z pianą, która została rozrobiona.

5. Podłącz zasilanie, włącz wentylator i pozwól mu najpierw pracować przez 30 sekund.



❹ POMPA WODY

OSTROŻNIE !!!

Podczas wyłączania najpierw należy wyłączyć pompę wody, a dopiero po 30 sekundach wyłączyć wentylator.

6. SCHEMAT URZADZENIA



Góra - to ZAMKNIĘTE
Dół - to OTWARTE

Włącznik Wentylatora

Włącznik Pompy

Bezpiecznik: Ochrona przed przepięciem i awarią zasilania. (Proszę go nie usuwać)



6. SPOSOB UZYTKOWANIA PREPARATU



Art. No F5900348

Proszek piankowy dostępny jest w różnych kolorach: czerwony, zielony, żółty, fioletowy, niebieski, biały lub w innych kolorach.

Proporcje: skala 1:200 i skala 1:300

Jeden kilogram pianki w proszku można zmieszać z 200l wody; jeden kilogram pianki w proszku można rozcieńczyć w 300l wody.

Proszek po wymieszaniu jest klarowny i przezroczysty.

UWAGA: TRUDNO JEST ODCZYŚCIĆ KOLOROWĄ PIANĘ. PROSZĘ UŻYWAĆ NARZĘDZI OCHRONNYCH.

7. CZYSZCZENIE I KONSERWACJA MASZYNY



Włącznik Pompy



1. Najpierw uruchom wentylator (min. 30 sek.), a następnie pompę wody.

Najpierw wyłącz pompę wody, a następnie wentylator.

2. Po użyciu maszyny pompa wody maszyny musi zostać WYŁĄCZONA, (jako pierwsza przed wentylatorem).

3. Włóż pompę wody do przygotowanej wody. Dociśnij maszynę pod kątem do minimum, opuść głowicę maszyny.

4. Ponownie włącz pompę wody maszyny, aż oczyści się czystą wodą.

5. Wytrzyj do czysta, złóż.

8. KWESTIE WYMAGAJĄCE UWAGI

1. Podczas przygotowań do operacji. Maszyna musi być WŁĄCZONA i WYŁĄCZONA, „Włącznik Pompy" jest w pozycji zamknięty.

2. Podczas czyszczenia „przełącznik pompy wody" musi być WYŁĄCZONY.

3. Proszę trzymać urządzenie poza zasięgiem dzieci.

4. Ze względu na dużą moc wentylatora nie należy dotykać wnętrza urządzenia, gdy jest ono włączone. Zasilanie musi być wyłączone.

5. Kolor pianki w proszku nie jest łatwy do czyszczenia. Proszę używać środków ochrony.

6. Kiedy maszyna do piany działa, proszę nie kierować strumienia piany na dzieci.

7. Jeśli piana dostanie się do oczu lub ust, proszę szybko oczyścić wodą. Jeśli nie czujesz się dobrze, zasięgnij porady lekarza.



FLASH

F5300003

www.flash-butrym.pl